

El software soporta: 3 rd, 5th edition and Symbian^3 phones.

Nokia C5, C6 C7, E5, E50, E51, E52, E55, E60, E61, E62, E63, E65, E66, E70, E71, E72, E73, E75, E90, N70, N71, N72, N73, N75, N76, N77, N78, N79, N8, N80, N81, N82, N85, N86, N90, N91, N92, N93, N95, N96, N97, 3250, 5228, 5230, 5233, 5235, 5320, 5500, 5530, 5630, 5700, 5730, 5800, 6110, 6120, 6121, 6122, 6124, 6210, 6220, 6260, 6290, 6650, 6710, 6720, 6730, 6760 Slide, 6788, 6790S, 6790 Surge, 6682, 6681, 6680, 6630, 7610, 6670, 6620, 6600, 6260, 3230, Nuron, X5, X6

Samsung SGH-i400, SGH-i450, SGH-i520, SGH-i550, SGH-i560, SGH-i570, L700, L780, L870, G810, i7110, i8510 INNOV8

Sony Ericsson Satio, Vivaz, Vivaz Pro

LG KS10, KT610, KT615